

## Solution 6000 system trouble messages


Modified on: Tue, 29 Jan, 2019 at 9:51 AM

This command lists any system troubles which are currently in effect on the system. information is displayed in a list format allowing you to select a particular event and then drill down to view more specific information.

System trouble events such as Failure To Communicate or Telco line Fail are grouped under System Trouble in the list while open zones are displayed individually one per line.

When the keypad is in standby mode, system troubles and open zones will be displayed on the status line of the keypad. From this mode you can access the list of troubles by pressing the down arrow.


- 1) Press [MENU] + [7] + [0] + [1] and use the up and down arrows to highlight the trouble event In the list then press [OK].



```

System Trbl
Zn1 Zone 1 Name
Zn2 Zone 2 Name
Press ▲▼ OK or MENU
  
```


- 2) Selecting System Trouble from the list will show the specific panel version Information to be displayed In the first two lines while the third line of the display will scroll all current system trouble events.



```

Panel 1
Solution 6000 Ver 2.00.00
Date and Time
Press OK or MENU
  
```


- 3) Selecting a Zone from the list will show the current zone state.



```

Zone 1 Name Zn1
EOL-Open 53020 ohms
Press OK or MENU
  
```

- 4) If no System Troubles are In effect the keypad will display.



```

There are no
System troubles
Press ▲▼ OK or MENU
  
```

- 5) Press [OK] or [MENU] when finished.

The following list shows the systems trouble messages including a description of what has caused the trouble event to occur. System Trouble events are also recorded in the System Event Log.

### Power Missing

This trouble message will display when the AC mains power supply to the panel is disconnected or failed and will clear when the power is reconnected. The Mains Power Icon in the keypad will also flash when the power is missing.

**AC Missing**

The control panel has detected that the AC mains supply has failed or is disconnected on an optional universal expander or LAN power supply module.

**Battery Low**

This trouble message will display if the panel's backup battery voltage has dropped below 11.5 volts DC during a battery test and will clear when the voltage is above 12.5 volts during a subsequent battery test.

**Battery Missing**

This trouble message will display if the panel detects that the system's backup battery is missing or has been disconnected.

**Low Battery**

The control panel has detected that an RF sensor has a low battery condition. Replace the RF sensor battery and transmit an RF signal to clear the low battery condition.

**Box Tamper**

The control panel has detected that the tamper circuit on the LAN power supply module is faulted. Place a shunt across the tamper input pins or close the tamper circuit to clear the box tamper trouble condition.

**Temperature Alert**

The control panel has detected that the console (eg. keypad, LAN reader or fingerprint reader) has exceeded the global temperature high or temperature low settings.

**Receiver Missing**

This trouble message will display if the panel detects the RF receiver is missing or disconnected. The trouble will clear when the receiver is reconnected.

**Case Tamper**

This trouble message will display if the panel detects that the tamper circuit on the RF receiver is faulted.

**Receiver Jam**

This trouble message will display if the connected RF receiver detects RF noise levels that may prevent it from working correctly.

**Comms Fail Route 1**

This trouble message will display if the panel has failed to send pending reports to Destination 1. All possible call attempts will be made before the trouble message is displayed.

**Comms Fail Route 2**

This trouble message will display if the panel has failed to send pending reports to Destination 2. All possible call attempts will be made before the trouble message is displayed.

**Comms Fail Route 3**

This trouble message will display if the panel has failed to send pending reports to Destination 3 (Email). All possible call attempts will be made before the trouble message is displayed.

**Sensor Watch Alert**

The control panel has detected a zone has failed to detect a change of state within the sensor watch period.

**Comms BUSS Trouble**

This trouble message will display if the panel failed to communicate to a system device which is connected to the LAN bus (e.g. keypad etc).

### **Default PIN Trouble**

This trouble message will display if the panel detects that either the installer PIN or User 1 PIN is still set to the factory default PIN. Change the PIN to clear the fault.

### **Date & Time**

This trouble message will display if the system date and time has not been set. Program the correct date and time to clear the fault at menu 7-1-0.

### **Cabinet Tamper**

This trouble message will display if the panel detects that it's cabinet tamper input is faulted. Close the tamper switch to clear the fault.

### **Connection Trouble**

The control panel has detected that an output device (eg. external siren etc) has failed or has been disconnected from the system.

### **Overload Condition**

The control panel has detected that an output has an over current condition.

### **Zone was in Alarm**

A zone was previously in alarm and requires alarm memory reset to clear. Turn the area on and then off again to clear alarm memory.

### **Telco Line Fall**

This trouble message will display if the panel detects that the telephone line has failed or been disconnected for a minimum of 30 seconds. The trouble will clear once the line has been restored for at least 1 minute.

### **LAN+ Overload**

This trouble message will display if the panel detects that the current load on the LAN+ power terminal has exceeded its maximum rating of 1 Amp DC. See MENU 7-3-2 — Fuse Options.

### **COMM+ Overload**

This trouble message will display if the panel detects that the current load on the COMM+ terminal has exceeded its maximum rating of 3 Amp DC. See MENU 7-3-2 — Fuse Options.

### **ACC+ Overload**

This trouble message will display if the panel detects that the current load on the +1 2V accessory power terminal has exceeded its maximum current rating of 1 Amp DC. See MENU 7-3-2 — Fuse Options.

### **Service Required**

This trouble message will display when the Service Interval Timer expires. To clear the message the installer must enter and exit programming mode. See MENU 2-9-2 — Service Interval.

### **Memory Checksum**

This occurs if the memory checksum is corrupted. To try and correct this, enter programming mode and make a programming change like a username then exit programming mode. if this problem still persists you must do a full system default.

**Phone Line in Use**

This trouble message will display while the panel is using the phone line. The message will clear when the line is released. This message can be prevented from displaying in MENU 5-2-2 — Phone Line Options.

**Battery Trouble**

The control panel has detected that the real time clock module has a low or missing backup battery.